

COMPLETE VACUUM SYSTEM

Vacuuming pin bones.
Visible hygiene results.



Efficient vacuuming of removed pin bones



Achieve a cleaner fillet and improve the working environment with the innovative vacuum system when removing pin bones with the Pin bone remover 400 system.

The system efficiently vacuums up pin bones and water, leaving both the fillet and the automatic pin bone remover clean and ready for processing. The Vacuum System removes approximately 90% of the water and bones.

Technology

The system has a 300-liter Cyclone Tank for collection of water and pin-bones from the pin-bone remover. The Vacuum System automatically drains the tank when processing.

It uses a mono pump for emptying the cyclone tank. The mono pump design allows for emptying the cyclone while keeping vacuum on the system. This ensures con-

stant suction at the rollers. Thus, there is no risk of backflow and contamination of the rollers. Pumping distance is up to 150 m. A plastic piping system connects the pin-bone machine to the cyclone tank.

It has a level sensor, an electronic control panel and an inspection door for easy cleaning access.

It includes a rack for placement on the floor. Alternatively, the tank can be fitted onto the wall. Maximum distance from the pin-bone remover is 9-12 m.

For automatic cleaning of the pin bone rollers, vacuum suction heads are mounted on the roller heads.



Technical specifications

Operators	None
Air consumption	10 L/min
Water consumption	4.8 L/min
Electrical connection	380/400 V

uni-food.com

Make believe.
Make sense.

